

EVAC 5EN INSTALLATION MANUAL



AMC 2013 - 002 Revision 2013-03-04

EN54-24:2008 0359-CPD-0213 TYPE A







1) Cut 172 mm diameter hole in the ceiling. Remove the grill with speaker body rotating anticlockwise with two 1 mm rods and pull it out from the speaker enclosure. Put in EVAC 5EN speaker enclosure into cut hole.




2) Relieve the spring mounting holders to fix the loudspeaker enclosure into the ceiling.




3) Punch the hole in fire dome, screw the cable gland and pass through it the cable.



4) Push up the fire dome until it lock's.



5) Connect cable with ceramic terminal and set up required power output on the line transformer. Push the grill with the speaker in to enclosure and rotate it clockwise until resistance appears.



EVAC 5EN Circuit Diagram



Neries krantinė 14A, LT-48397 Kaunas, Lithuania **Phone** +370 37 308585, 308584 **Fax** +370 37 308583 **E-mail** info@amcpro.eu **Web** www.amcpro.eu